

FIG. 1





FIG. 2



008760" E8E49960




FIG. 3*FIG. 4*

FIG. 5




00554383 091800

FIG. 6

JOB																			
OPTION (O) HELP (H)																			
PRINTER STATUS	IN-SPOOLER JOB	IN-DEVICE JOB	PORT																
<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div> <p>DOCUMENT : WWWWWWWWWWWWWWWWWWWWWWWWWWWWWW</p> <p>OWNER : WWWWWWWWWWWWWWWWWWWWWWWWWWWWWW</p> <p>SIZE : WWWW KB</p> </div> </div> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 40%;">DOCUMENT</th> <th style="width: 20%;">STATUS</th> <th style="width: 20%;">OWNER</th> <th style="width: 20%;">SIZE</th> </tr> </thead> <tbody> <tr> <td>▷ SUM 1.x0s</td> <td>PRINTING</td> <td>THIRO</td> <td>32</td> </tr> <tr> <td>○ SUM 1.x0s</td> <td>WAITING</td> <td>THIRO</td> <td>32</td> </tr> <tr> <td>○ SUM 1.x0s</td> <td>WAITING</td> <td>THIRO</td> <td>32</td> </tr> </tbody> </table>				DOCUMENT	STATUS	OWNER	SIZE	▷ SUM 1.x0s	PRINTING	THIRO	32	○ SUM 1.x0s	WAITING	THIRO	32	○ SUM 1.x0s	WAITING	THIRO	32
DOCUMENT	STATUS	OWNER	SIZE																
▷ SUM 1.x0s	PRINTING	THIRO	32																
○ SUM 1.x0s	WAITING	THIRO	32																
○ SUM 1.x0s	WAITING	THIRO	32																

FIG. 7



A screenshot of a printer status window. The window has a title bar with a close button (X). Inside, there is a printer icon with a status indicator (a square with a circle and an X). To the right of the icon, the text reads: DOCUMENT : SUM 3.x0s, ENDED : 1999/10/18, RESULT : INTERRUPT PRINT FAILED. Below this, separated by a horizontal line, are the details: USER : YAMA, PRINTER : LPPP, PORT : LP1. At the bottom right, there is a button labeled "DELETE THIS NOTICE".

DOCUMENT	: SUM 3.x0s
ENDED	: 1999/10/18
RESULT	: INTERRUPT PRINT FAILED
<hr/>	
USER	: YAMA
PRINTER	: LPPP
PORT	: LP1
<div>DELETE THIS NOTICE</div>	

FIG. 8




FIG. 9




FIG. 10

PROPERTY OF PRINTER?✕

MAIN

PAPER

LAYOUT

DEVICE OPTION

OVERLAY

EJECT

PAGE COMPOSER

JOB MODE :

☒ PRINT (R)

☐ INTERRUPT PRINT (I)

☐ BIN SORTER (L)

PAPER
EJECTION (F) :

NO REGISTRATION

DELIVER TO (O) :

EJECTION TRAY

☐ PRINT COPY BY COPY USING HD (M)

RETURN TO
DEFAULT (D)

OK

CANCEL

ADAPT (A)

HELP

FIG. 11




FIG. 12




FIG. 13




FIG. 14




FIG. 15




FIG. 16

POINTER
1601

JOB ID	SUSPENSION FLAG
1	F
2	F
3	F
4	F

16-1

POINTER
1601

JOB 5
ADDED

JOB ID	SUSPENSION FLAG
1	F
2	F
3	F
4	F
5	F

16-2

POINTER
1601

JOB ID	SUSPENSION FLAG
2	F
3	F
4	F
5	F

JOB 1 PRINTED
OR CANCELLED

16-3

FIG. 17





FIG. 18

FIG. 19

MEMORY MAP OF MEM MEDIUM
(FD, CD-ROM ETC.)

DIRECTORY
PROGRAM CODES FOR FLOWCHART OF FIG. 3
PROGRAM CODES FOR FLOWCHART OF FIG. 4
PROGRAM CODES FOR FLOWCHART OF FIG. 5
PROGRAM CODES FOR FLOWCHART OF FIGS. 12 AND 13
PROGRAM CODES FOR FLOWCHART OF FIG. 14
PROGRAM CODES FOR FLOWCHART OF FIG. 17

009160-EEH9960